
2 on 2 Audio Board Manual

E. F. Bavis & Associates, Inc.

201 Grandin Road
Maineville, Ohio 45039
(513) 677-0500

Removal & Installation Instructions

1. Power down the audio system by unplugging the power from the wall source.
2. Remove all Molex plugs from the back of the console and open the case.
3. Disconnect the button panel ribbon connector and all components from the board.
4. Remove the #4-40 nuts from the board.
5. Remove the heat sink from the back case (if needed).
6. Remove the board.
7. Making sure that the standoffs are still on the studs, install the new board (Note: the heat sink is now located on the board and does not need to be remounted to the case).
8. Attach the board with (3) of the #4-40 nuts removed in step 4 and the (2) 5/8" long hex standoffs provided in this kit. (Note: the standoffs go into the (2) corners at the button board end.)
9. Re-connect all components and button board ribbon connector.
10. Re-connect all Molex plugs into the back of the console and close the case making sure not to pinch any of the wires.
11. Power up the unit and test.
12. Adjust audio pots for desired audio levels.