

---

# **TA Video Interface Installation Instructions**

---

**E. F. Bavis & Associates, Inc.**

---

201 Grandin Road  
Maineville, Ohio 45039  
(513) 677-0500

## Universal TA Video Interface Installation Instructions

**Note: The Universal TA Video Interface board can support up to 3 phones per drive thru lane.**

1. Plug the RJ11 lead from the Universal TA Video Interface board into the “Phone Connection” port on the Universal TA Interface box.
2. Connect the dry contact leads from the Video Interface board to the camera/monitor leads. Green is common while black, red, and white control the different feeds.
3. Plug the transformer into the power input jack. (Power LED should light up and stay lit.)
4. Plug the telephone(s) into the phone ports on the board.
5. When the telephone is off hook, the line LED for that phone should light up and the camera/monitor should come on.

If you have any questions please consult the factory at (513) 677-0500

