



201 Grandin Road
Maineville, Ohio 45039
(513) 677-0500

Trimless Window Installation Manual

Copyright 2017 E. F. Bavis & Associates, Inc.
All Right Reserved

Revised: 08/03/2017
PN: 00707011

Installation Instructions for Trimless Windows

Window Installation Accessories

Part #	Description
00707011	Window Installation Manual
06973011	5/8 Hole Plugs
93402622	#8 x 2-1/2" Phil Pan SM
95284318	1/4 x 1-3/4" Hex Slotted Tapcon
12011040	Polyurethane Construction Sealant
12011061	Wood Shims

Window Installation Procedure

1. Inspect the window for any damage that may have occurred during shipping.
2. Check the dimensions of the masonry opening (refer to table below).
3. Caulk two even beads on the bottom of the masonry opening. Extend the beads 3" up both sides.
4. Slide the window into place & insure that the window is level.
5. Place the shims behind the mounting holes on the side and top and anchor the window with the hardware provided.
6. Place the 5/8 hole plugs into the mounting holes.
7. Caulk the window on the outside.

Window Dimensions Checklist

Window	Width	Height	Masonry Opening Width	Masonry Opening Height
32" Basic	32"	33 1/4"	32 1/2"	33 1/2"
42" Basic	42 1/4"	35 7/8"	42 3/4"	36 3/8"
60" Basic	56"	33 1/4"	56 1/2"	33 1/2"
65" Basic	64 7/8"	35 7/8"	65 3/8"	36 3/8"
3'	32"	32 3/4"	32 1/2"	33"
5'	56"	32 3/4"	56 1/2"	33"
8'	88 3/8"	32 3/4"	88 7/8"	33"
10'	111 1/2"	32 3/4"	112"	33"
12'	138 1/8"	32 3/4"	138 5/8"	33"

SHIM INSTALLATION



