
Ceiling Trim Ext. Manual

E. F. Bavis & Associates, Inc.

201 Grandin Road
Maineville, Ohio 45039
(513) 677-0500

Copyright 2012 E. F. Bavis & Associates, Inc.
All Rights Reserved

Revised 02/10/12
P/N 00761011

Bill of Material

Part Number	Description	Quantity
04050012	CC ½ Surface Mount Box (CC Only)	2
04050011	TT ½ Surface Mount Box (TT Only)	2
93101623	#8 x ½ Self Drilling SMS	20
00761011	Ceiling Trim Ext. Manual	1

CAUTION

There Must Be At Least 12 Inches From The Ceiling Trim To The Start Of The Twist Tube.

Installation Instructions

Refer to the Diagram on the Next Page

1. Remove the ceiling trim from the ceiling and let the trim slide down until it rests on the control. Be sure that you do not scratch the vertical tube doing this.
2. Check and make sure that you have a solid surface to mount the trim box to the ceiling. Install braces if needed.
3. Put the two halves of the surface mount trim box around the vertical tube and assemble with the #8 x ½ self drilling sms provided.
4. Mount the trim box to the ceiling.
5. Raise the ceiling trim to the surface mount trim box and mount to the box with the #8 x ½ self drilling sms provided. Be sure that when you move the ceiling trim that you do not scratch the vertical tube.
6. Mount the ceiling trim to the vertical tube with the #8 x ½ self drilling sms provided.
7. Test the unit to make sure that the car does not hang up in the ceiling trim or hit the ceiling trim/trim box going in and out.
8. Repeat this procedure for the other ceiling trim if needed.

Surface Mount Trim Box Mounting Diagram



