



201 Grandin Road
Maineville, Ohio 45039
(513) 677-0500

BD2 Bill Trap Bar Kit

TOOLS NEEDED

PENCIL
TAPE MEASURE
DRILL
3/16 DRILL BIT
PHILIPS HEAD SCREW DRIVER
CENTER PUNCH
DEBURRING TOOL

MEASURE FOR HOLES

1. With the Red Bin fully extended to the outside, pull tape measure from front, inside of the Red Bin back (4 inches) mark on the inside vertical wall of the Red Bin.
2. (REPEAT ON OTHER SIDE)
3. On the 4" mark measure up from the inside bottom of the Red Bin (1 Inch)
4. (REPEAT ON OTHER SIDE)
5. Center punch in the center where the two marks meet.
6. Drill holes out with a 3/16 drill bit.
7. Deburr the holes.
8. Place the Bill Trap Bar Block inside the Red Bin, so that the opening of the cut out in the block is facing down.
9. Align the pilot hole up in the center of the 3/16 hole drilled into the Red Bin.
10. Pushing down firmly on the Block, fasten the block to the Red Bin with the #8 screw provided.
11. Place the Bill Trap Bar in the Red Bin, with one end of it inside the Bill Trap Bar Block.
12. Place the remaining Block inside of the Red Bin, making sure the Blocks opening is facing down and over the other end of the Bill Trap Bar, and secure it to the opposite side.



