Transaction DrawerTM

Nut Replacement Manual

For Kit 00502992

E. F. Bavis & Associates, Inc.

201 Grandin Road Maineville, Ohio 45039 (513) 677-0500

Transaction DrawerTM Nut Replacement Parts Included

TD Acetal Nut		
TD Nut to Drawer Mount		
TD Maintenance Grease Kit		
10-32 x 1/2" Slotted Hex machine		
Screws (4)		

Installation Tool List

¹ / ₈ " Allen Wrench		
7/16" Socket or Wrench		
5/16" Socket or Wrench		
¹ / ₄ " Nut Driver or #2 Phil		
Screwdriver (depends on model)		
Blue Loctite		
Dry Cloth or Paper Wipes		

Procedure

- 1. Disconnect the power to the drawer.
- 2. Remove the inside back cover.
- 3. Remove the (2) 1/4-20 nuts connecting the Nut to Drawer Mounting Plate to the Red Bin and remove the plate. (Note: Use caution when removing the Drawer Mounting Plate as the Red Bin will slide completely out of the TD Shell)
- 4. Remove the four button cap screws holding the motor in place from the bottom of the drawer shell with a ¹/₈" Allen wrench for the early style or a 5/16" socket for the later version. (Note: Screws were installed with Loctite so you may need to apply heat to the screws to release the Loctite so the screws will turn)

- 5. Slide the motor off of the Threaded Rod and move out of the way. (The Threaded Rod can now be removed to be wiped clean) Note: **Do not** use solvents to clean drawer parts, just wipe clean with a dry cloth or towel.
- 6. Remove the Rod to Motor key and remove the old Nut off of the Threaded Rod and install the new one.
- 7. Grease the Threaded Rod and other Drawer parts then re-install the Motor key.
- 8. Install the Rod and Nut assembly back into the Drawer, then re-attach the Motor.
- 9. Fasten the motor to the drawer using Blue Loctite on the 10-32 x 1/2" Hex screws that were provided.
- 10. Center the Red Bin in the black plastic slides and reconnect the Red Bin to the Nut with the new Drawer Mounting Plate.
- 11. Reinstall the back panel.
- 12. Reconnect the power and test for proper operation.

For further questions or help, contact the Factory at 513-677-0500.